

Parts Required: Base Apron Pad – Color & Width specific

Step	Execution	Figures
1	Slide the flap, on the top (straight side) of the PR Apron over the black plastic plug, found underneath the pedal rocker. Cover both the left & right sides.	
2	Wrap the strap & buckle around the crossbar & attach the plastic buckles. Tighten	

- 3** View of attached apron from the underside of the chair.



For more information, please contact Broda Customer Care at 1-800-668-0637