


Instruction: Back Pad Installation

Approval: Rob Deans

Document Number:	SWI-07-088
Revision No.:	0
Revision Date:	3-Oct-12
Written By:	Ashley

Step	Tools	Qty	Hardware	Qty	Broda Part	Execution	Figures
Step 1						<p>Position the back pad with the mesh material against the vinyl straps. The tags should be positioned at the top of the back frame and the narrow end of the pad towards the bottom of the back frame.</p>	
Step 2						<p>The back pad does not have any straps to secure, therefore it will sit freely in an upright position against the back frame.</p> <p>*Note the back pad and covers are width and height specific. The covers are color specific.</p>	
						<p>Please contact Broda Customer Service with questions or concerns at 800-668-0637</p>	

Hardware List		
Check	QTY	ITEM